

## CFP2 API Documentation

### Table of Contents

1. Introduction .....	2
1.1. Acronyms and abbreviations.....	2
2. APIs.....	2
2.1. General Functions .....	2
2.1.1. USB Connection .....	2
A. ConnectToHost .....	2
B. Disconnect.....	2
C. GetDeviceCount .....	2
2.1.2. Monitoring .....	2
A. P3V3_Current_Monitor .....	2
2.2. CFP2 MSA functions .....	3
2.2.1. MDIO access.....	3
A. Read_Mdio.....	3
B. Write_Mdio.....	3
2.2.2. Alarms and controls signals .....	3
A. MOD_ABS.....	3
B. RX_LOS .....	3
C. GLB_ALRM.....	4
D. PRG_ALRM1 .....	4
E. PRG_ALRM2 .....	4
F. PRG_ALRM3 .....	4
G. TX_DIS .....	4
H. MOD_LOPWR.....	5
I. MOD_RST.....	5
J. PRG_CNTL1 .....	5
K. PRG_CNTL2 .....	5
L. PRG_CNTL3 .....	5
M. Set_PRTADR .....	6
3. Document information .....	6

## CFP2 API Documentation

### 1. Introduction

This document describes the various API functions for the Multilane CFP2 host boards (ML4027, ML4027-ACO and ML4042). Each function is described with its parameters and return values.

#### 1.1. Acronyms and abbreviations

API	Application Programming Interface
DLL	Dynamic Link Library (.dll file)
USB	Universal Serial Bus
MDIO	Management Data Input Output

### 2. APIs

#### 2.1. General Functions

##### 2.1.1. USB Connection

###### A. ConnectToHost

<b>Description</b>	Opens a USB connection to CFP2 Host
<b>Call</b>	bool __stdcall ConnectToHost(UInt16 Instance)
<b>Parameters</b>	UInt16 Instance: USB instance of plugged host
<b>Returns</b>	True or False

###### B. Disconnect

<b>Description</b>	Disconnects from CFP2 Host and close open USB connection
<b>Call</b>	bool __stdcall Disconnect(UInt16 Instance)
<b>Parameters</b>	UInt16 Instance: USB instance of plugged host
<b>Returns</b>	True or False

###### C. GetDeviceCount

<b>Description</b>	Gets the number of devices attached
<b>Call</b>	UInt32 __stdcall GetDeviceCount(void)
<b>Parameters</b>	None
<b>Returns</b>	Number of connected devices

##### 2.1.2. Monitoring

###### A. P3V3\_Current\_Monitor

<b>Description</b>	Measures current value on the 3.3V line
<b>Call</b>	bool __stdcall P3V3_Current_Monitor(UInt16 Instance, UInt16* data)
<b>Parameters</b>	UInt16 Instance: USB instance UInt16* data: Current value in mA
<b>Returns</b>	True or False

## CFP2 API Documentation

### 2.2. CFP2 MSA functions

#### 2.2.1. MDIO access

##### A. Read\_Mdio

<b>Description</b>	Reads MDIO
<b>Call</b>	bool __stdcall Read_Mdio(UInt16 Instance, UInt8 DeviceAddress, UInt16 RegisterAddress, UInt16* data)
<b>Parameters</b>	UInt16 Instance: USB instance UInt8 DeviceAddress: Device address UInt16 RegisterAddress: Register address UInt16* data: Pointer to the value to be read
<b>Returns</b>	True or False

##### B. Write\_Mdio

<b>Description</b>	Writes MDIO
<b>Call</b>	bool __stdcall Write_Mdio(UInt16 Instance, UInt8 DeviceAddress, UInt16 RegisterAddress, UInt16 data)
<b>Parameters</b>	UInt16 Instance: USB instance UInt8 DeviceAddress: Device address UInt16 RegisterAddress: Register address UInt16 data: Value to be written
<b>Returns</b>	True or False

#### 2.2.2. Alarms and controls signals

##### A. MOD\_ABS

<b>Description</b>	Reads Module Absent CFP2 pin to check if the CFP2 module is inserted in the Host
<b>Call</b>	bool __stdcall MOD_ABS(UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if module is absent False if module is present
<b>Returns</b>	True or False

##### B. RX\_LOS

<b>Description</b>	Receiver Loss Of Signal pin status
<b>Call</b>	bool __stdcall RX_LOS (UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if RX_LOS is High False if RX_LOS is Low
<b>Returns</b>	True or False

## CFP2 API Documentation

### C. GLB\_ALARM

<b>Description</b>	Global alarm state (inverse of GLB_ALARMn pin)
<b>Call</b>	bool __stdcall GLB_ALARM(UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if GLB_ALARM asserted False if GLB_ALARMn is deasserted
<b>Returns</b>	True or False

### D. PRG\_ALARM1

<b>Description</b>	Programmable Alarm 1 pin status
<b>Call</b>	bool __stdcall PRG_ALARM1(UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if PRG_ALARM1 asserted False if PRG_ALARM1 is deasserted
<b>Returns</b>	True or False

### E. PRG\_ALARM2

<b>Description</b>	Programmable Alarm 2 pin status
<b>Call</b>	bool __stdcall PRG_ALARM2(UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if PRG_ALARM2 asserted False if PRG_ALARM2 is deasserted
<b>Returns</b>	True or False

### F. PRG\_ALARM3

<b>Description</b>	Programmable Alarm 3 pin status
<b>Call</b>	bool __stdcall PRG_ALARM3(UInt16 Instance, bool* status)
<b>Parameters</b>	UInt16 Instance: USB instance bool* status: True if PRG_ALARM3 asserted False if PRG_ALARM3 is deasserted
<b>Returns</b>	True or False

### G. TX\_DIS

<b>Description</b>	Asserts/Deasserts TX_DIS
<b>Call</b>	bool __stdcall TX_DIS(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert TX_DIS False to deassert TX_DIS
<b>Returns</b>	True or False

## CFP2 API Documentation

### H. MOD\_LOPWR

<b>Description</b>	Asserts/Deasserts MOD_LOPWR
<b>Call</b>	bool __stdcall MOD_LOPWR(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert MOD_LOPWR False to deassert MOD_LOPWR
<b>Returns</b>	True or False

### I. MOD\_RST

<b>Description</b>	Asserts/Deasserts MOD_RSTs (inverse of MOD_RSTn pin)
<b>Call</b>	bool __stdcall MOD_RST(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert MOD_RSTn pin (Reset state is asserted) False to deassert MOD_RSTn pin (Reset state is deasserted)
<b>Returns</b>	True or False

### J. PRG\_CNTL1


<b>Description</b>	Asserts/Deasserts PRG_CNTL1
<b>Call</b>	bool __stdcall PRG_CNTL1(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert PRG_CNTL1 False to deassert PRG_CNTL1
<b>Returns</b>	True or False

### K. PRG\_CNTL2

<b>Description</b>	Assert/Deassert PRG_CNTL2
<b>Call</b>	bool __stdcall PRG_CNTL2(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert PRG_CNTL2 False to deassert PRG_CNTL2
<b>Returns</b>	True or False

### L. PRG\_CNTL3

<b>Description</b>	Assert/Deassert PRG_CNTL3
<b>Call</b>	bool __stdcall PRG_CNTL3(UInt16 Instance, bool asserted)
<b>Parameters</b>	UInt16 Instance: USB instance bool asserted: True to assert PRG_CNTL3 False to deassert PRG_CNTL3
<b>Returns</b>	True or False



## CFP2 API Documentation

### M. Set\_PRTADR

<b>Description</b>	Sets MDIO Physical Port Address
<b>Call</b>	bool __stdcall Set_PRTADR(UInt16 Instance, UInt8 value)
<b>Parameters</b>	UInt16 Instance: USB instance UInt8 value: Desired port address value
<b>Returns</b>	True or False

### 3. Document information

Revision number	Author	Date
1.0	Mary Daou	4/30/2015